Instruction Set of 8086

Gursharan Singh Tatla

professorgstatla@gmail.com

Instruction Set of 8086

- An instruction is a binary pattern designed inside a microprocessor to perform a specific function.
- The entire group of instructions that a microprocessor supports is called Instruction Set.
- 8086 has more than **20,000** instructions.

Classification of Instruction Set

- Data Transfer Instructions
- Arithmetic Instructions
- Bit Manipulation Instructions
- Program Execution Transfer Instructions
- String Instructions
- Processor Control Instructions

- These instructions are used to transfer data from source to destination.
- The operand can be a constant, memory location, register or I/O port address.

• MOV Des, Src:

- Src operand can be register, memory location or immediate operand.
- Des can be register or memory operand.
- Both Src and Des cannot be memory location at the same time.
- E.g.:
 - MOV CX, 037A H
 - MOV AL, BL
 - MOV BX, [0301 H]

• PUSH Operand:

- It pushes the operand into top of stack.
- E.g.: PUSH BX

• POP Des:

- It pops the operand from top of stack to Des.
- Des can be a general purpose register, segment register (except CS) or memory location.
- E.g.: POP AX

- XCHG Des, Src:
 - This instruction exchanges Src with Des.
 - It cannot exchange two memory locations directly.
 - E.g.: XCHG DX, AX

• IN Accumulator, Port Address:

- It transfers the operand from specified port to accumulator register.
- E.g.: IN AX, 0028 H

OUT Port Address, Accumulator:

- It transfers the operand from accumulator to specified port.
- E.g.: OUT 0028 H, AX

- LEA Register, Src:
 - It loads a 16-bit register with the offset address of the data specified by the Src.
 - E.g.: LEA BX, [DI]
 - This instruction loads the contents of DI (offset) into the BX register.

LDS Des, Src:

- It loads 32-bit pointer from memory source to destination register and DS.
- The offset is placed in the destination register and the segment is placed in DS.
- To use this instruction the word at the lower memory address must contain the offset and the word at the higher address must contain the segment.
- E.g.: LDS BX, [0301 H]

• LES Des, Src:

- It loads 32-bit pointer from memory source to destination register and ES.
- The offset is placed in the destination register and the segment is placed in ES.
- This instruction is very similar to LDS except that it initializes ES instead of DS.
- E.g.: LES BX, [0301 H]

21-Nov-2010 www.eazynotes.com

11

• LAHF:

It copies the lower byte of flag register to AH.

• SAHF:

It copies the contents of AH to lower byte of flag register.

• PUSHF:

Pushes flag register to top of stack.

POPF:

Pops the stack top to flag register.

ADD Des, Src:

- It adds a byte to byte or a word to word.
- It effects AF, CF, OF, PF, SF, ZF flags.
- E.g.:
 - ADD AL, 74H
 - ADD DX, AX
 - ADD AX, [BX]

- ADC Des, Src:
 - It adds the two operands with CF.
 - It effects AF, CF, OF, PF, SF, ZF flags.
 - E.g.:
 - ADC AL, 74H
 - ADC DX, AX
 - ADC AX, [BX]

• SUB Des, Src:

- It subtracts a byte from byte or a word from word.
- It effects AF, CF, OF, PF, SF, ZF flags.
- For subtraction, CF acts as borrow flag.
- E.g.:
 - SUB AL, 74H
 - SUB DX, AX
 - SUB AX, [BX]

SBB Des, Src:

- It subtracts the two operands and also the borrow from the result.
- It effects AF, CF, OF, PF, SF, ZF flags.
- E.g.:
 - SBB AL, 74H
 - SBB DX, AX
 - SBB AX, [BX]

• INC Src:

- It increments the byte or word by one.
- The operand can be a register or memory location.
- It effects AF, OF, PF, SF, ZF flags.
- CF is not effected.
- E.g.: INC AX

• DEC Src:

- It decrements the byte or word by one.
- The operand can be a register or memory location.
- It effects AF, OF, PF, SF, ZF flags.
- CF is not effected.
- E.g.: DEC AX

AAA (ASCII Adjust after Addition):

- The data entered from the terminal is in ASCII format.
- In ASCII, o 9 are represented by 30H 39H.
- This instruction allows us to add the ASCII codes.
- This instruction does not have any operand.

Other ASCII Instructions:

- AAS (ASCII Adjust after Subtraction)
- **AAM** (ASCII Adjust after Multiplication)
- AAD (ASCII Adjust Before Division)

- DAA (Decimal Adjust after Addition)
 - It is used to make sure that the result of adding two BCD numbers is adjusted to be a correct BCD number.
 - It only works on AL register.
- DAS (Decimal Adjust after Subtraction)
 - It is used to make sure that the result of subtracting two BCD numbers is adjusted to be a correct BCD number.
 - It only works on AL register.

• NEG Src:

- It creates 2's complement of a given number.
- That means, it changes the sign of a number.

CMP Des, Src:

- It compares two specified bytes or words.
- The Src and Des can be a constant, register or memory location.
- Both operands cannot be a memory location at the same time.
- The comparison is done simply by internally subtracting the source from destination.
- The value of source and destination does not change, but the flags are modified to indicate the result.

• MUL Src:

- It is an unsigned multiplication instruction.
- It multiplies two bytes to produce a word or two words to produce a double word.
- AX = AL * Src
- DX : AX = AX * Src
- This instruction assumes one of the operand in AL or AX.
- Src can be a register or memory location.

• IMUL Src:

• It is a signed multiplication instruction.

• DIV Src:

- It is an unsigned division instruction.
- It divides word by byte or double word by word.
- The operand is stored in AX, divisor is Src and the result is stored as:
 - AH = remainder AL = quotient

• IDIV Src:

• It is a signed division instruction.

• CBW (Convert Byte to Word):

- This instruction converts byte in AL to word in AX.
- The conversion is done by extending the sign bit of AL throughout AH.

CWD (Convert Word to Double Word):

- This instruction converts word in AX to double word in DX : AX.
- The conversion is done by extending the sign bit of AX throughout DX.

- These instructions are used at the bit level.
- These instructions can be used for:
 - Testing a zero bit
 - Set or reset a bit
 - Shift bits across registers

• NOT Src:

- It complements each bit of Src to produce 1's complement of the specified operand.
- The operand can be a register or memory location.

• AND Des, Src:

- It performs AND operation of Des and Src.
- Src can be immediate number, register or memory location.
- Des can be register or memory location.
- Both operands cannot be memory locations at the same time.
- CF and OF become zero after the operation.
- PF, SF and ZF are updated.

OR Des, Src:

- It performs OR operation of Des and Src.
- Src can be immediate number, register or memory location.
- Des can be register or memory location.
- Both operands cannot be memory locations at the same time.
- CF and OF become zero after the operation.
- PF, SF and ZF are updated.

• XOR Des, Src:

- It performs XOR operation of Des and Src.
- Src can be immediate number, register or memory location.
- Des can be register or memory location.
- Both operands cannot be memory locations at the same time.
- CF and OF become zero after the operation.
- PF, SF and ZF are updated.

SHL Des, Count:

- It shift bits of byte or word left, by count.
- It puts zero(s) in LSBs.
- MSB is shifted into carry flag.
- If the number of bits desired to be shifted is 1, then the immediate number 1 can be written in Count.
- However, if the number of bits to be shifted is more than
 1, then the count is put in CL register.

• SHR Des, Count:

- It shift bits of byte or word right, by count.
- It puts zero(s) in MSBs.
- LSB is shifted into carry flag.
- If the number of bits desired to be shifted is 1, then the immediate number 1 can be written in Count.
- However, if the number of bits to be shifted is more than 1, then the count is put in CL register.

• ROL Des, Count:

- It rotates bits of byte or word left, by count.
- MSB is transferred to LSB and also to CF.
- If the number of bits desired to be shifted is 1, then the immediate number 1 can be written in Count.
- However, if the number of bits to be shifted is more than 1, then the count is put in CL register.

• ROR Des, Count:

- It rotates bits of byte or word right, by count.
- LSB is transferred to MSB and also to CF.
- If the number of bits desired to be shifted is 1, then the immediate number 1 can be written in Count.
- However, if the number of bits to be shifted is more than
 1, then the count is put in CL register.

- These instructions cause change in the sequence of the execution of instruction.
- This change can be through a condition or sometimes unconditional.
- The conditions are represented by flags.

• CALL Des:

- This instruction is used to call a subroutine or function or procedure.
- The address of next instruction after CALL is saved onto stack.

• RET:

- It returns the control from procedure to calling program.
- Every CALL instruction should have a RET.

• JMP Des:

 This instruction is used for unconditional jump from one place to another.

• Jxx Des (Conditional Jump):

• All the conditional jumps follow some conditional statements or any instruction that affects the flag.

Conditional Jump Table

Mnemonic	Meaning	Jump Condition
JA	Jump if Above	CF = o and $ZF = o$
JAE	Jump if Above or Equal	CF = o
JB	Jump if Below	CF = 1
JBE	Jump if Below or Equal	CF = 1 or ZF = 1
JC	Jump if Carry	CF = 1
JE	Jump if Equal	ZF = 1
JNC	Jump if Not Carry	CF = o
JNE	Jump if Not Equal	ZF = o
JNZ	Jump if Not Zero	ZF = o
JPE	Jump if Parity Even	PF = 1
JPO	Jump if Parity Odd	PF = o
JZ	Jump if Zero	ZF = 1

• Loop Des:

- This is a looping instruction.
- The number of times looping is required is placed in the CX register.
- With each iteration, the contents of CX are decremented.
- ZF is checked whether to loop again or not.

- String in assembly language is just a sequentially stored bytes or words.
- There are very strong set of string instructions in 8o86.
- By using these string instructions, the size of the program is considerably reduced.

CMPS Des, Src:

• It compares the string bytes or words.

• SCAS String:

- It scans a string.
- It compares the String with byte in AL or with word in AX.

- MOVS / MOVSB / MOVSW:
 - It causes moving of byte or word from one string to another.
 - In this instruction, the source string is in Data Segment and destination string is in Extra Segment.
 - SI and DI store the offset values for source and destination index.

- REP (Repeat):
 - This is an instruction prefix.
 - It causes the repetition of the instruction until CX becomes zero.
 - E.g.: REP MOVSB STR1, STR2
 - It copies byte by byte contents.
 - REP repeats the operation MOVSB until CX becomes zero.

Processor Control Instructions

- These instructions control the processor itself.
- 8086 allows to control certain control flags that:
 - causes the processing in a certain direction
 - processor synchronization if more than one microprocessor attached.

Processor Control Instructions

• STC:

• It sets the carry flag to 1.

• CLC:

• It clears the carry flag to o.

• CMC:

It complements the carry flag.

Processor Control Instructions

• STD:

- It sets the direction flag to 1.
- If it is set, string bytes are accessed from higher memory address to lower memory address.

• CLD:

- It clears the direction flag to o.
- If it is reset, the string bytes are accessed from lower memory address to higher memory address.

Thank You Have a Nice Day



www.eazynotes.com 23-Nov-10 47